


Description of 5G CPE Ports and Indicators

1. 5G CPE Interfaces



2. Indicator Description

Indicator	Name	Description
①	Cellular Network Indicator	1) Blue , signal value RSRP≥ -95dBm 2) Yellow , signal value RSRP < -95dBm
②	5G Indicator	1) On , Connect to 5G network 2) Off , Disconnect with 5G network 3) Blink , dialing, blink frequency 500ms/time
③	4G Indicator	1) On , Connect to 4G network 2) Off , Disconnect with 4G network 3) Blink , dialing, blink frequency 500ms/time
④	WiFi Indicator	1) On , WIFI on 2) Blink : After press the WPS button , 500ms/time , continue 2 minutes 3) Off , WIFI off
⑤	Power Indicator	1) On , Power on 2) Off , Power off

3.Button Description

Button	Description
⑥ WPS	1. After the button is pressed, the WiFi indicator light will blink 500ms/time for 2 minutes. 2. The user terminal can quickly establish a secure WIFI connection without manually entering a password
⑦ Power	1. After the button is pressed, the WiFi indicator light will blink 500ms/time for 2 minutes. 2. After Devices Shutdown: Plug and unplug the power supply, it will automatically turn on. 3. After Shutdown: Long press the power button for 3s, turn on the device.
⑩ RESET	Press and hold the button for more than 10 seconds to reset to the factory setting.

4.Interfaces Description



Interfaces	Name	Description
⑧	PHONE (Optional)	Phone RJ11 port, can directly connect the phone to make calls
⑨	LAN2/WAN	1) Indicator is green and steady on, it is connected 2) Indicator is yellow and blinking, data is transmitt or receive
⑩	LAN1	1) Indicator is green and steady on, it is connected 2) Indicator is yellow and blinking, data is transmitt or receive
⑪	Power	DC 12V/3A
⑫	SIM Card	Insert the Nano-SIM card
⑬	Type C	The type-c interface is used only R&D personnel testing

2. Set up SIM Card or Wired Broadband Internet Access

Can choose SIM card or wired broadband connect to network

SIM Card


Step 1 :
Insert SIM card direction shown as below (Chip face down, notch face in)



Wired Broadband Network

Step 1 :
Network cables can only be connected to LAN2/WAN network ports.

Step 2 :
Connect the power supply, the device will turn on automatically



Step 3 : Connect to network devices

Mobile phones, tablets and other devices are connected to Yeacomm 5G CPE wireless networks


The desktop computer is connected to the LAN port of Yeacomm 5G CPE through a network cable



Default Password : 12345678

Step 4: Open the browser, and the page is automatically displayed. (If no, manually enter 192.168.1.1)

Default Account : admin
Default Password : admin



Step 5: Setting the user name and password for the WLAN





2.4GHz



5GHz

Step 6: Set the password for logging in to the host



After the application setting is completed, the login page will be displayed. Enter the password of the new account and click login.



Precautions:

If you use the Yeacomm NR330 5G Router with a T-Mobile sim card, pls do the setting manually as follows to make it connect to internet.

1. Choose Networking Mode "NSA" setting.(Network settings---Mobile Network---Mobile network settings)
2. Choose IP Type "IPV4" settings. (Network setting---Mobile Network ---Advanced settings)



Tech Support

Website: www.yifanwireless.com

Email: support@yifanrouter.com